



SiHL Design2wall papers can be used on all interior walls and ceilings.

Wall preparation The base surface should be carefully prepared:

- Remove all old wallpaper – to remove the remains of old paste try using a squirting bottle with water and a few squirts of washing up liquid. This works perfectly well on most wallpaper paste.
- Remove peeling paint remnants
- Smooth out any rough surfaces – although the glass-fibre and glass textile products will cover small cracks and uneven surfaces.
- Clean with a damp cloth
- Prior to beginning all surfaces should be dry.

STYLE

SiHL non-prepasted products

- We recommend the use of Metylan pastes (standard non-woven wallpaper paste) – or similar solvent-free products (solvent based / or dispersion pastes can result in the removal of inks)
- We recommend the use of protective gloves (soft cotton) when wallpapering to protect the inks.
- Paste the wall / or surface
- Hang the way one would hang any non-woven wallpaper
- Use a damp cloth to remove any excess wallpaper paste from the media.

STYLE

+ SiHL prepasted products

- Printed, cut panels
- We recommend the use of protective gloves (soft cotton) when wallpapering to protect the inks.
- Submerge cut panels in water to activate the paste – unwind the panels in the water to ensure activation of all the paste.
- Hang the way one would hang any other non-woven wallpaper